

A simple 3 step  
drain process  
to winterize your system



State of the Art  
in Watering  
Since  
1957

For systems with a Pressure Vacuum Breaker backflow prevention device

**Step 1: Shut the water to the system off**




Your *shut off* is located: \_\_\_\_\_




Turn the ball valve handle to a perpendicular position [ 1/4 turn ]. The cap on the drain port must also be opened to allow the water to drain out. It is recommended to do this last after step 2 and 3 so as not to drip water anywhere.

**Step 2: Winterize the Vacuum Breaker [ two things to do ]**


A) Turn the two blue handled ball valves to a 45 degree angle position.




B) Open the two test cocks 1/4 turn using a standard screwdriver



**Step 3: Open all of the faucet drains in the manifold [ generally 1 per group of valve boxes ]. As well as any other faucets located along the outside plumbing.**



**\* If your system has any drip filters in the manifold boxes, these should also be opened.**



**!! IMPORTANT !!**

**Don't forget to go back and open that cap on the drain port on the main shut off valve back in step one, if not all ready done.**

**Please turn your controller to off and leave plugged in whenever possible.**

**Thank you for choosing B & B Sprinklers. If you have any questions or need to schedule a service appointment please call our office @ [509] 466-7550.**